

ROASTER CENTOVENTI

USER AND SERVICE MANUAL



1. General information	5	3. Moving and transportation section	26
1.1. Structure of the manual	4	3.1. General norms	26
1.2. Messages Used	4	3.2. Packaging	26
1.3. Aim and contents	4	3.3. Transportation	26
1.4. Preservation of the manual	5	3.4. Removal of the packaging	27
1.5. External components	6	4. Installation section	27
1.6. Internal components	8	4.1. Positioning	27
1.7. Details of the manufacturer	18	4.2. Electrical connections	27
1.8. Identification plate of the machine	18	4.3. Installation of the machine	28
1.9. Identification plate of the CE marking	18	5. Operation section	29
1.10. Inteded use	18	5.1. Description of the controls	29
1.11. Operating environment	18	5.2. Using the machine	30
1.12. Noise level	18	5.3. Alarms	35
1.13. Technical characteristics	19	6. Maintenance section	36
1.14. Dimensions	19	6.1. General information	37
1.15. Storage	20	6.2. General safety practice	37
1.16. Disposal	20	Cleaning and maintenance	35
1.17. Warranty	20	7. Technical diagrams section	39
1.18. person qualified to operate	21	7.1. Electrical circuit diagram	39
2. Safety section	22	8. Spare part section	48
2.1. Safety information	22		
2.2. Safety limitations	22		
2.3. Safety symbols and plaques	23		
2.4. Safety and protection devices	23		
2.5. Client's safety measures	24		
2.6. Personal protection equipment	24		
2.7. Residual risks	25		
2.8. Applied Directives	25		
2.9. Harmonized technical norms	25		

1. General information

1.1. Structure of the manual

To simplify the reading and understanding of the information contained in this manual and to make searches quicker, it has been divided into sections, each dedicated to a specific subject.

1.2. Messages used

Attention

This type of message is used to draw the reader's attention to more delicate or particular procedures which, if not carried out correctly, may pose a risk to the safety of the operator and cause damage to parts of the machine.

Warning

This type of message is used to draw the reader's attention to procedures which, if not carried out correctly or at pre-set intervals, may cause damage to the machine or its parts, as well as to the product being processed.

Environment

Messages relating to the environment draw the operator's attention to the rules to be followed to prevent the risk of environmental damages deriving, directly or indirectly, from use of the machine.

Note

These messages highlight instructions, advice and notes that can be particularly helpful during the various uses of the machine.

1.3. Aim and contents

This manual has been drawn up in consideration of the requirements of directive 2006/42/EC and paying particular attention to describing all the procedures necessary to obtain the best working conditions for the machine and its operators, without neglecting product quality:

The aim of this manual is, therefore, to provide the user with all the information necessary for the correct use and maintenance of the machine. Consequently it is absolutely necessary:

- to meticulously follow the instructions given in the manual during every phase of the machine's life, from transportation to demolition;
- for every machine operator to thoroughly read the contents of this manual;
- for the company's safety officer to make sure that all machine operators have clearly understood how the machine works

Attention

In case of doubts on the correct interpretation of the instructions please contact the manufacturer to obtain the necessary clarifications. All those carrying out any kind of operation on the machine must have thoroughly read and understood the contents of this instruction manual.

Warning


If this manual is damaged or lost, please ask the manufacturer or the authorised distributor in the country where the machine is being used for another copy.

1.4. Preservation of the manual

The instruction manual is an integral part of the machine and must be used to train and inform professional figures operating on the machine. Consequently, it is necessary to follow certain simple instructions regarding its preservation, as follows:


- store the manual in areas protected from humidity and heat, so as not to jeopardise the quality or legibility of any part of the publication;
- keep the manual in an easily accessible place known to the machine operators;
- avoid handling the manual with dirty or greasy hands;
- if you think it is necessary to highlight important steps of the manual, use non-permanent systems, to preserve its legibility;
- do not remove, rip or rewrite any parts of the manual for any reason.

1.5. EXTERNAL COMPONENTS




- 1) Exhaust system roasting area
- 2) Exhaust system of the cooling area
- 3) Product exit
- 4) Electrical power supply

EXTERNAL COMPONENTS




- 1) Filters area
- 2) Skin collector
- 3) Side protection
- 4) Pipe for loading the product
- 5) Exhaust pipe roasting area

1.6. BACK SIDE OF THE MACHINE WITHOUT THE PROTECTION




- 1) Exhaust system roasting area
- 2) Filters
- 3) Exhaust system of the cooling area
- 4) Skin collector

UPPER PART WITHOUT THE PROTECTION




- 1) Charging container
- 2) Window control of the roasting chamber
- 3) Roasting chamber
- 4) Control panel
- 5) Cooling chamber
- 6) Blower for charging the product
- 7) Exhaust system roasting area
- 8) Sensor level
- 9) Emergency button
- 10) Start/Reset button

UPPER PART WITHOUT THE PROTECTION



- 1) Loadign hopper
- 2) 3 handles to keep the hopper cover closed
- 3) Pipe for the product loading by aspirating it.
- 4) Valve to let the product fall into the roasting chamber
- 5) Lights for the roasting chamber
- 6) Piston for the valve opening

UPPER PART WITHOUT THE PROTECTION




1

2

3



- 1) Roasting chamber side blower
- 2) Electrical resistance for the side blower
- 3) Roasting chamber

LEFT SIDE WITHOUT THE PROTECTION CARTER




- 1) Roasting chamber bottom blower
- 2) Electrical resistance bottom blower
- 3) Connection between the roasting and the cooling chamber
- 4) Cooling chamber
- 5) Compressed air supply
- 6) Manometer
- 7) Electrical valves group
- 8) Electrical power supply

DETAIL OF LEFT SIDE WITHOUT THE PROTECTION



- 1) Air temperature probe (bottom)
- 2) Electrical resistance
- 3) Pipe coming from the bottom blower

DETAIL OF LEFT SIDE WITHOUT THE PROTECTION




1





- 1) Pipe to clean the roasting cone

RIGHT SIDE WITHOUT PROTECTION CARTER




- 1) Mixer motor for the cooling chamber
- 2) Piston for the opening/closing of the roasting chamber cone
- 3) Exit of the finish product
- 4) Cooling fan
- 5) Piston for unload the product
- 6) Exhaust pipe of the cooling chamber
- 7) Exhaust pipe for the aspiration blower

DETAIL OF UPPER PART WITHOUT THE PROTECTION




- 1) Heart product temperature probe
- 2) Air temperature probe (side)
- 3) Air compressed blow

ELECTRICAL PANEL



- 1) Electrical panel cooling fan
- 2) Electrical panel door security micro
- 3) Power board
- 4) Inverter blower 1
- 5) Inverter blower 2
- 6) Heating elements relay
- 7) Main contactor
- 8) Safety module
- 9) Relay
- 10) Transformer
- 11) 220 V Fuse protection
- 12) Ground connection

POWER BOARD



1. Absorption control bottom electrical resistance
2. Absorption control side electrical resistance
3. Mixer motor connection
4. Cooling fan connection
5. Charging product blower connection
6. 380V protection fuses
7. Connection 380V
8. Connection 24V a.c.
9. Air compressed for clean the cone
10. Solenoid pneumatic actions
 - A. Opening the roasting cone
 - B. Unload product
 - C. Air compressed blow
11. Fan cooling electrical panel
12. lights roasting chamber connection
13. Relay Heating resistance
14. empty
15. Sensor level charging container
16. Inverter roasting chamber bottom blower connection
17. Inverter roasting chamber side blower connection
18. Probes connections
19. Flat cable connection
20. 24V protection fuse

1.7. Details of the manufacturer

The machine described in this instruction manual was built by:

SELMi S.r.l.

Via Statale, 151 – 12069 – S. Vittoria D'Alba (CN) Italia
Tel. 0172.479273 - 0172.479275 - Fax 0172.477814
www.selmi-group.it - info@selmi-group.it

1.8. Identification plate of the machine (CE marketing)

There is a plate, similar to the one shown here, on the machine, indicating details of the manufacturer, the CE conformity mark and the machine's serial number. Always state this number when communicating with the manufacturer.



Example of identification plate on the machine structure

TYPE
SERIAL NUMBER
YEAR
WEIGHT

1.9. Identification plate of the CE marking electric panel (low voltage)

Example of identification plate on electrical panel. For the correct data, see the data shown in the section on the machine's technical specifications.



1.10. Inteded use

Roaster Centoventi was designed to work on a continuous cycle of automatic processing, it has a tank capacity of 20/25Kg and has the ability to roast 50Kg of coffee or dried fruit per hour. It uses an original and exclusive air cyclone system (vertiflow® patent) which has a temperature sensor at the heart of the product. It is particularly versatile for the roasting of coffee, hazelnuts, almonds, pistachios and any other appropriate product...The machine has a number of programs which control the heating temperature, the roasting time, the cooling time and the final automatic discharge of the products. The programs can be personalised to obtain the desired grade of roasting time after time.

Warning

A use other than that specified is considered improper. The machine is intended for professional use only.

Attention

Do not place any small objects near the control panel or the tank: they could fall and enter the tank, which would contaminate the product.

1.11. Operating environment

To guarantee proper functioning the machine must be protected from atmospheric agents. Its ambient operational temperature should be between 15C° and 35C° with relative humidity not exceeding 70%.

The working environment must be clean, sufficiently illuminated and away from an explosive environment.

The environmental characteristics of the installation site are specified in section 4.

Attention

The machine's fixed guards have a variety of openings to allow the internal units to cool. When the machine is running, make sure that these openings are not covered by cloths or objects that obstruct proper air flow.

1.12. Noise level

The phonometric tests carried out on this specific machine model show an acoustic pressure lower than 70 dB(A).

TECHNICAL CHARATERISTICS


Roasting chamber capacity:	20/25 Kg
Roasting chamber material:	inox AISI 304 L
Heating:	Electrical resistances
Controls:	Double electronical card
Weight:	500 Kg

Power installed:	35 kW
Voltage supply:	380V
Number of phases:	3
Frequency:	50Hz or 60Hz*
Noise	< 80 dB
Protection degree:	IP65

Air compressed required	220 l/min
Maximum load Power:	6 bar minimum
Air characteristics	Dry and deoiled and filtered

* This data can change according to the contractual installation conditions. For correct data refer to the plate inserted inside the electric panel.

Dimensions



1.15. Storage

Remove the remaining product left in the machine following the instructions in the appropriate section. Stop the machine using the main switch and disconnect it from the electricity main. Move it to a spacious place (it is necessary to work all around the machine).

Clean the tank, the removable components (i.e. screw pump, mixer, nozzle) and the pipes as described in the appropriate section.

Attention

It is absolutely necessary to follow the instructions in order to insure the safety of the operators and to avoid damaging the machine's removable parts.

Use a brush to cover the movable components and the mechanical moving parts with a thin layer of food grade lubricant. This can later be removed with an alkaline de-greaser (Sodium Hydroxide) if the machine needs to be re-installed.

Carry out the same operation on the machine surfaces, taking care of avoiding the heating elements located in the inner part of the machine.

Gather the parts (use as reference the delivery packing list) and put them in the original packaging. Place packets of hygroscopic salt based on silica gel in the packaging.

Store all the parts in a sheltered place away from atmospheric agents and in temperatures from 0° C to 40° C. Cover the parts with nylon in order to prevent the accumulation of dust.

1.16. Disposal

Disposal will occur at the end of the working life of the machine, which under normal conditions of use and maintenance will be over ten years.

In the case of disposal all the components of the machine will have to be disposed of in adequate waste yards according to the legislation in force.

Before disposal it will be necessary to separate the plastic or rubber parts and the electrical and electronic material.

Environment

Parts made solely of plastic, aluminium and steel can be recycled in the appropriate collection centres.

According to the RoHS regulations electronic boards and electric material should be recycled separately in authorised collection centres.

1.17. Warranty

The manufacturer offers a warranty on this machine model for a period of 24 months from the purchase date, as shown on the fiscal document issued at the time the machine is delivered.

The warranty will be void if the machine is repaired by a third non authorized party or if fixtures and accessories not supplied by or recommended or approved by the manufacturer are used.

The warranty will also be void upon removal or alteration of the plate showing the serial number and other data.

Within the warranty period the manufacturer will repair or replace, free of charge, parts that are faulty due to manufacturing.

In case the repair has to take place at the manufacturer's site, the machine will have to be sent to the manufacturer in its original packaging.

Transportation expenses will be covered by the manufacturer during the warranty period.

The warranty does not cover the cleaning of the functioning parts.

Defects not clearly attributed to the material or the manufacturing will be examined. If the claim should turn out to be unjustified all repair expenses, changed parts and transportation will be charged to the buyer.

The warranty does not cover damage caused by the following:

- accidental damage during transportation
- damage due to lack of care or procedures carried out incorrectly
- damage due to improper use not conforming to the warnings of the user and service manual
- components subject to wear and tear; a detailed list is available in the components section.

Structural damage, modifications, improper alterations or repairs can affect the functioning of the safety mechanisms, thus making the declaration of conformity and warranty void. Alterations on the machine can be carried out solely by technicians authorised by the manufacturer.

1.18. Person qualified to operate the machine

The machine must only be used by authorized and purposely trained personnel; the same precautions are also applicable to personnel who carry out maintenance.

Personnel who do routine and extraordinary maintenance must be specially trained professionals; good knowledge of the machine is needed for extraordinary maintenance.

Attention

Do not permit others to approach the machine during its use or maintenance.

The following professional people, after having received all the necessary instructions, are the only ones allowed access to the machine:

Safety officer

The safety officer is responsible for protection and prevention of risks in the workplace, as is mentioned in European Directive 89/391/EEC (Safety in the workplace), introduced in Italy with the 12/11/1994 Legislative Decree.

It is the responsibility of the safety officer to make sure that all personnel who use/maintain the machine have received all the instructions regarding their relative roles contained in this manual.

Operator (user of the machine)

Operator trained and qualified for the use of the machine (working cycle, potential adjustments, etc.).

He/she can only carry out the specific tasks described in this manual reserved for this role.

Mechanical maintenance technician

The technician is qualified to use the machine as the OPERATOR and furthermore to use it with the protection disabled, to attend to the mechanical parts for adjustments, maintenance and reparations.

He/she is not qualified to act on live electrical installations.

The mechanical maintenance technician must have a generic knowledge of the machine and a specific knowledge on this machine model.

Electrical maintenance technician

The technician is qualified to use the machine as the OPERATOR and furthermore to use it with the protection disabled, to attend to the adjustments and electrical installations for the purposes of maintenance and repair.

If qualified, he/she may work when the electrical panels, control devices, are live, provided he/she uses appropriate personal protective devices.

The electrical maintenance technician must have a generic understanding of the electrical panels and specific knowledge on the electrical panel and components of this machine.

Manufacturer

The manufacturer's personnel are qualified to perform all of the above-described operations.

Any operations not described in this manual may be performed ONLY by personnel authorized by the manufacturer.

2. Safety section

2.1. Safety information

Attention

The safety officer has the obligation to inform the workers on the risks related to the use of the machine.

Furthermore the employer must inform, educate and train the user according to statutory laws.

The lack of compliance with the basic norms or precautions could result in accidents during the functioning, maintenance or reparations of the machine. Accidents can often be avoided by acknowledging potential hazardous situations before they materialise. The operator must pay attention to the potential dangers and have the training, the competence and the necessary equipment to deal with these tasks correctly.

The manufacturer cannot be held responsible for accidents or damages resulting from the use of the machine by personnel not adequately trained or having used the machine improperly, as well as the lack of, even partial, compliance to the safety norms and interventions procedures contained in this manual.

The safety precautions and the warnings messages, the operator could be subject to accidents with serious consequences for himself and for other people.

In cases where tools, procedures, work methods or working techniques not explicitly suggested by the manufacturer are used, it will be necessary to make sure that no dangers are present for the individual carrying them out and to other alike.



Use exclusively original SELMI spare parts. The manufacturer will take no responsibility for accidents or damages in the case of use of non-original spare parts.

If a tool not supplied by the manufacturer is installed on the machine, the client needs to make sure that the norms stated in Directive 2006/42/EC are adhered to. If this new tool introduces new risks to the system then the new system must be re-certified. In any case the manufacturer cannot be held responsible for accidents or damages caused by the machine if it has been modified or equipped with non original accessories.

2.2. Safety limitations

Attention

The indications mentioned hereafter cannot completely safeguard from all dangers that one might encounter while using the machine; they must be used in conjunction with common sense and the experience of the operator, the only indispensable measures for the prevention of injury.

Every section has a list of specific safety measures for different operations. The safety measures mentioned here below are generic and should be followed for all procedures on the machine.

The responsibilities assigned to specific people concerning the use of the machine must be clearly defined as stated in the "Qualified Personnel" section.

Attention

The use of the machine is forbidden to personnel who have not been authorised or trained by the safety officer.

Consult the manufacturer before carrying out procedures that are not mentioned in this manual.

Prolonged overloads or anomalies can cause the electric motors and electrical appliances to overheat with resultant harmful fumes. In such cases immediately disconnect the machine from the mains and do not approach the machine until such fumes have been dispersed via adequate ventilation. In case of fires do not use water jets on the machine – use CO2 extinguishers instead.

The operator, any helping technician and the maintenance technician must use the appropriate personal protection equipment when working on the machine.

It is forbidden to climb on the machine.

Do not touch the electrical wires, switches, buttons etc. with wet hands.

The parts subject to wear and tear during the functioning of the machine must be checked and replaced as soon as they present noticeable signs of wear and tear.

The manufacturer has designed and built the machine to last for a reasonable time with the Client's normal conditions of use in mind; it is however necessary to periodically check the components and the structure of the machine, paying attention to any anomalous conditions, such as, for example, cracks or deformations. If necessary, contact the manufacturer to ask for a complete check of the machine.

Please consult Section 4 (Installation) for the working environmental conditions of the machine.

2.3. Safety symbols and plaques

The machine has a number of plaques with symbols and and/or safety messages stuck to it.

Attention

Make sure that all the safety messages are legible and in good condition.

Replace the damaged plaques with the new ones from the manufacturer. If a plaque happens to be on a part that is being replaced, make sure that a plaque is present on the new piece.

ATTENTION

THE PERFORMANCE OF WORK ON ELECTRICAL EQUIPMENT CONNECTED TO THE POWER SUPPLY IS STRICTLY FORBIDDEN

- ANY EXCEPTIONS MUST BE AUTHORISED BY THE EXECUTIVE MANAGER
- IN PARTICULARLY DANGEROUS SITUATIONS, ANOTHER PERSON MUST BE PRESENT IN ADDITION TO THE PERSON PERFORMING THE WORK

WORK MAY ONLY BEGIN WHEN THE SAFETY MEASURES HAVE BEEN IMPLEMENTED

IN OBSERVANCE OF PRESIDENTIAL DECREE 543 ON THE PREVENTION OF ACCIDENTS



(positioned on the door of the electrical panel)



Label indicating compulsory reading of the manual
(positioned on the front of the machine)

2.4. Safety and protection devices

Attention

The components shown here are particularly important for the safety of the operator and the machine. In cases of malfunction or wear they must be replaced with spare parts supplied or authorized by the manufacturer.

While the machine is in use all the protection devices must be correctly installed.

The safety devices present on the machine are:

- Mushroom emergency button with mechanical unblock mechanism.



There is an emergency stop mushroom button on the machine. Pushing it cuts voltage to all live parts by means of appropriate devices. To reset it, release the emergency button by turning its head and then push the RESET button shown in the photo.

Before starting every shift, press it to make sure that it works properly.

- *Protective devices*

The machine is equipped with protective plates that can be removed with a tool to allow access to the inside of the machine in order to carry out maintenance operations.

The fixed protective plates are screwed into position and can be removed with the appropriate tool; if the screws are removed the fixed protective plates will not remain in place and must be placed on the floor.

All the protective plates have smoothed and rounded edges for the safety of the exposed individual and of the operators.

The protective plates have loss-proof screws that remain attached to the plate when it is removed from the machine.

Attention

Do not switch the machine on if the protective panels are removed or not correctly fixed into position with the appropriate screws.

Do not forget to remove cloths, keys or utensils used for the maintenance operation from within the machine.

Before closing with the protective panels and switching on the machine check carefully and if necessary remove any extraneous objects which may be present inside the machine.

All protection and safety devices must always be kept in perfect working conditions. If faulty, they must be immediately repaired or replaced.

The replacement, disengagement, partial or total removal of the protective plates, safety devices and protective structures must only be carried out during maintenance operations. This also applies to the safety plaques attached to the side of the machine.

2.5. Client's safety measures

The client must arrange for the following safety measures to be in places:

Provision of an adequate location for installation, paying particular attention to the characteristics below:

- Adequate flooring
- Normal and emergency lighting
- Adequate ventilation
- Clearly signposted emergency exits
- Provision of mains voltage connection with associated safety devices, conforming with the norms in force and the characteristics of the machine
- Adequate means for the collection and subsequent disposal of residues, even hazardous or special ones (oils and grease, broken or waste material, etc.).
- Adequate fire safety systems and equipment
- Prohibition of entry into the installation area to non authorized personnel

The customer must also provide for:

- Training of the operators and the maintenance technicians
- Training for the operators on the basic functioning of the machine and emergency devices
- Provision of personal safety equipment to protect the operator and the hygiene of the product
- Checking the qualifications of external maintenance technicians potentially called to work on the machine
- Keeping of a maintenance log book

The employer is also responsible for checking that the operators correctly carry out the procedures explained in this manual.

2.6. Personal protection equipment

The operators who carry out functions on the machine must receive appropriate instructions on the use of personal protection equipment such as shoes, gloves, etc... which will protect them from residual risks derived from the execution of various activities. The operators must furthermore be equipped with protection equipment for hygiene purposes (caps or hair nets, gown, etc...).

If the noise level in the working environment surpasses 85dB(A) appropriate ear protection must be used.

Warning

The clothing of whoever operates or carries out maintenance on the machine must conform to the essential safety requirements defined by European directive and the laws in force in the country in which the machine is installed.

Attention

During maintenance operations individuals must wear adequate clothing to prevent the occurrence of accidents.

In order to avoid mechanical risks such as snagging or dragging, it is prohibited to wear particular objects such as bracelets, watches, rings or necklaces during the working cycle and during maintenance operations.

2.7. Residual risks

The accurate risk analysis carried out by the manufacturer and archived in the technical file has eliminated most of the residual risks, which are nevertheless present during the use of the machine, to acceptable levels.

The manufacturer's recommendation is to meticulously adhere to the instructions, procedures and recommendations contained in this manual.

Attention

It is strictly prohibited to carry out any type of mechanical or electrical modification so as not to create added dangers and unforeseen risks.

Attention

Keep the machine with the residual chocolate inside the tank in an adequate environment with temperatures ranging from 10 °C to 25 °C.

The residual risks present on the machine are:

Risks during machine transportation

It is recommended to fasten the machine, or its parts, at the dedicated locations and lift it with appropriate means to the minimum permitted height, proceed at low speeds and make sure that the people helping with the moving are at a safe distance from the moving object. Before moving the machine make sure that the passage is clear and that there are no objects placed on the machine. It is important that the means of support and transportation is controlled by a person qualified for such a role, so as to avoid unforeseen movements which may be dangerous to the people in the vicinity who are helping with the moving.

Risks of faults to the circuits of signalling, safety, protection and emergency stop

In the case of a circuit fault, the safety and signaling circuits, the anti-injury protections and the emergency stop can lose their effectiveness, therefore it is asked that their functionality is periodically checked.

Identified residual risks and information plaques

The manufacturer has placed on the machine danger and/or warning plaques, based on the residual risks, with pictograms in compliance with the norm pertaining to the display of graphic symbols on the machine.

The user should immediately replace these plaques if they are not clearly legible.

Attention

It is expressly forbidden to remove the safety and/or warning plaques placed on the machine. The manufacturer will not take any responsibility on the safety of the machines if this is not observed.

Risk to life (electrolocation)

Before commencing work on any electrical appliance it is necessary to disconnect the machine from the mains. If it were to become necessary to work within the electric panel by bypassing the electricity cut off devices, then the work must be carried out exclusively by specialised personnel.

Risk of spreading fire

In case of fire never use jets of water in the vicinity of the apparatus. Disconnect all connections to the mains and use the appropriate CO2 extinguishers located in the building.

2.8. Applied Directives

The following directives apply to the machine described in this manual:

- 2006/42/EC machinery Directive
- 2014/30/UE Directive for electromagnetic compatibility
- 2017/35/UE low voltage Directive

And the regulation:

- 1935/2004 EC regulation for materials in contact with foodstuffs

2.9. Harmonized technical norms

The machine was designed and tested to conform to the "essential requirements to health and safety" present in attachment I of European Directive 2006/42/EC.

The norms used as reference for the design, the realization and the testing of the machine are listed in the technical file archived by the manufacturer.

3. Moving and transportation section

3.1. General norms

Before moving the machine always check the weight and general instructions shown on the packaging. Personnel not responsible for the movement of the machine must not remain in the area needed for movement.

3.2. Packaging

The machine is delivered on a platform, secured by means of straps and placed inside a cardboard packaging which is also secured to the platform by means of straps. An example of the machine packaging is shown in the picture below.



Instructions for transportation are on the sides of the packaging.

The first symbol shows the correct upright position of the packaging;




the second symbol shows that the packaging must be protected from the rain;

the third symbol shows that the content of the packaging is fragile and must be handled with care. On two sides of the packaging there is a device called "TILTWATCH", which can determine if the packaging has been tilted to such an extent that the content may have been damaged; it is necessary to pay attention to the instructions given on the adhesive label. If the machine has been excessively tilted during transportation (the dot at the centre of the TILTWATCH



device will be red) some components could have been damaged.



3.3. Transportation

To transport the machine it is necessary to use a suitable vehicle equipped with a platform to lift the



Attention

The manufacturer's warranty does not cover damage during transportation; the buyer should follow the instructions on the adhesive label in order to avoid disputes.

load; the platform must be adequate for the weight of the machine, which is stated in the technical characteristics section (section 1.13). When the machine, still in its packaging, is in the body of the lorry, it can be carried to the lifting

platform only by means of a manual transportation trolley for euro pallets.

The lifting platform has to be equipped with side rails in order to prevent the machine from falling when it is still high off the ground.

The machine can be lowered to the ground from the platform only after having lowered the manual trolley. The machine should be lowered slowly from the platform, avoiding shaking and sudden stops which could cause a loss of stability.

After having completed the unloading procedures, the machine should be moved exclusively by means of a manual transportation trolley adequate for euro pallets; the platform should only be lifted to the height needed to move the machine.

Before moving the machine verify that the passage to the final destination is clear.

Attention

Do not go on very steep ramps which could cause the loss of control of the trolley.

3.4. Removal of the packaging

Cut the straps that anchor the cardboard to the platform; remove the cardboard and put it out of the way.

Cut the straps that hold the machine to the platform, remove the machine's plastic cover and unravel the accessories provided.

Carefully lift the front of the machine and remove the wooden slat blocking the front wheels; subsequently remove also the wooden slat blocking the rear wheels by lifting the back of the machine.

Very carefully lower the machine from the platform.

Note

Keep the original packaging; it may be necessary to use it if the machine needs to be sent to the manufacturer for extraordinary maintenance or repairs.



4. Installation section

4.1. Positioning

Warning

Before positioning the machine check that the machine, the associated accessories and the parts supplied separately have not been damaged during transportation.

It is the task of the Client to make sure that the strength of the supporting surface, at the point of installation, is adequate for the weight of the machine.

The flooring at the point of installation must be sufficiently level.

Isolate the machine from any potential vibrations coming from other nearby machinery.

In the case where the machine or any of the associated accessories are found damaged it is important to alert the manufacturer of the found anomaly so as to agree on the actions to be taken.

Attention

The machine must be placed on a level surface; for the other environmental requirements necessary for optimal functioning of the machine please see sections 1.11 and 2.5..

4.2. Electrical connections

Attention

The connection of the machine to the electrical system must be carried out by personnel observing the legislation in force; the characteristics of the electrical connection must be compatible with the electrical specifications of the machine which can be found in the relevant section or on the apposite plaque on the door of the electric panel.

Attention

If the machine has been purchased to be powered by a three phase line, make sure that in the socket there is a connection to the neutral wire. This is necessary for the functioning of the machine.

Attention


Before starting any procedure make sure that there are no objects inside the tank.

4.3. Air compressed connection

In the picture below is shown the position of the air connection plug.

Attention

Make sure the pressure is around 2 bar. The air compressed must be disoiled and disidratated.



air compressed connection

5. Operation section

CONTROL PANEL

The Roaster machine is equipped with a touch screen; here there are the display pages


1- Home page

Push on the
"Selmi roasting machines"
logo to go to the next page




2 - Roasting mode page

- A. Normal roasting
- B. Curve Roasting



NORMAL ROASTING WORKING PAGE

When in the roasting cycle, the product arrive to the set temperature the machine end the roasting cycle and start the cooling process




1. HOME to return to the home page.
2. START to start the roasting cycle.
3. STOP to stop the working process.
4. Blower intensity: pushing the orange button it's possible to modify the air intensity.
5. Air temperature: pushing the orange button it's possible to modify the Air Temperature; The RED value beside is the temperature read by the probe.
6. Heart product temperature: pushing the orange button it's possible to modify the Heart product Temperature; The RED value beside is the temperature read by the probe.
7. Roasting Graphic: On the X value there is the temperature and on the Y value there is the time.
8. Roasting time.
9. Unload final product. You can set the time for unload the finish product.
10. Light: Turn ON OFF the light in the roasting chamber.
11. Right and Left arrow: pushing the left arrow it will appear the previous or next recipe.
12. Cooling cycle button: You can set the time for cooling.
13. Roasting chamber unload product; You can set the time for unload the product into the cooling chamber.
14. Valve opening: to let the product fall into the roasting chamber press OPEN
15. Recipe name: pushing on the recipe name is possible to change the name of the recipe.
16. Button for loading the product into the hopper. To load the product push the button and proceed by aspirate the product.

WORKING PAGE CURVE ROASTING

Using this way for roasting is possible to split the roasting cycle in 4 steps.

Each one of them can have different settings.



1. HOME to return to the home page.
2. START to start the roasting cycle.
3. STOP to stop the working process.
4. Blower intensity: pushing on the numbers it's possible to modify the air intensity for each phase.
5. Air temperature: pushing on the numbers it's possible to modify the air temperature for each phase.
6. Working time for each phase.
7. Watch that shows the roasting time progression
8. Watch that shows the cooling time countdown and after that the unloading product countdown.
9. Roasting Graphic: On the X value there is the temperature and on the Y value there is the time.
10. Temperature in real time: roasting air coming from the lower blower
11. Temperature: it's shown in real time the temperature of the roasting chamber heart
12. Temperature in real time: roasting air coming from the higher blower
13. Unload final product. You can set the time for unload the finish product.
14. Light: Turn ON OFF the light in the roasting chamber.
15. Right and Left arrow: pushing the left arrow it will appear the previous or next recipe.
16. Cooling cycle button: You can set the time for cooling.
17. Roasting chamber unload product; You can set the time for unload the product into the cooling chamber.
18. Recipe name: pushing on the recipe name is possible to change the name of the recipe.
19. Valve opening: to let the product fall into the roasting chamber press OPEN
20. Button for loading the product into the hopper. To load the product push the button and proceed by aspirate the product.

HOW TO USE THE MACHINE

1. Be sure to have the air compressed and electricity connected.

2. Load the product aspirating it as the images below




3. Be sure to have a bowl under the final product exit on the right side of the machine



4. The machine can work in a continue cycle, When the machine start the cooling cycle it's possible to start another roasting cycle and so on.

TIPS



NOTE: The icons A and B have also a button function. This means that holding the button you go directly to the cooling process. This is an emergency skip in case the roasting cycle programmed is too long or wrong.

KEYBOARD

Orange buttons have a variable value that you can set. pushing on them it will appear a keyboard that let you modify the value and then return (pushing enter) to the previous page



5.2. USING THE MACHINE

1. Connect the machine to the supply line.
2. Connect the machine to the air compressed.
3. Connect the exhaust pipes to the right exhaust system.
4. Switch on the *Roaster "Centoventi"*

Note: we advice to keep the blue lever on the right side of the machine open (up position) when the machine roast dry fruits such as almonds and hazelnuts.

SUGGESTED SETTINGS FOR ROASTER

	PRODUCT	FAN	AIR TEMP.	TEMP. PROD.
1	"Light" hazelnuts	90%	220° - 240° C	165° C
2	Medium Roasted Hazelnut	90%	220° - 240° C	173° C
3	"Dark" Hazelnut	90%	220° - 240° C	185° C
4	Skinned "Light" Almond	90%	220° - 240° C	135-140° C
5	Skinned "Dark" Almond	90%	220° - 240° C	170° C
6	Almond with Skin	90%	220° - 240° C	160° C
7	Pistachio	90%	220° - 240° C	150-155° C
8	Peanut	90%	220° - 240° C	170-175° C
9	Cashew	90%	220° - 240° C	165° C
10	Macadamia	90%	220° - 240° C	170° C
11	Cocoa Bean	90%	220° - 240° C	145° C
12	Pine nut	90%	220° - 240° C	140° C
13	Coffee	90%	220° - 240° C	218-220° C
14	Deca Coffee	90%	220° - 240° C	210-215° C

5.3. ALARMS

TIPOLOGIA ALLARME	POSSIBILE PROBLEMA
ALARM HEATER 1	The heater is absorbing more than the limit set into the parameters
ALARM HEATER 2	Only roaster centoventi
ALARM BLOWER 1	The blower is absorbing more than the limit set into the parameters
ALARM BLOWER 2	Only roaster centoventi
ALARM COOLING	The fridge is absorbing more than the limit set into the parameters
ALARM STIRRER	Only roaster centosei and centoventi
ALARM ASPIRATOR	Only roaster centoventi
MAINTENANCE	
CHANGE FILTERS CONTACT THE FACTORY	
EMPTY SKIN COLLECTOR	
BURNING RISK CONTINUE ONLY IF YOU CHANGED THE FILTER	
BURNING RISK CONTINUE ONLY IF THE TRAY IS CLEAN	
EMPTY BASKET	Only roaster centodue
INSERT BASKET	Only roaster centodue
ABSENCE BASKET	Only roaster centodue
WRONG TEMPERATURE DELTA THERMAL HEAT	Data not valid

**ROASTING CHAMBER CONFIGURATION:
WHICH CONFIGURATION USE FOR EACH PRODUCTION**

COFFEE



COCOA BEANS



DRIED FRUIT



6. Maintenance section

6.1. General information

Attention

If a bacterial presence is found on the product derived from the processing carried out with this machine model it will be necessary to stop production immediately and contact the manufacturer for the disinfection procedures.

Warning

Extraordinary maintenance on the machine is exclusively carried out by the technicians approved by the manufacturer.

The training course carried out only gives the client the base instructions for ordinary maintenance. The manufacturer suggests carrying out a full service every two years to guarantee the safety conditions.

Note

The maintenance technician must note on an appropriate logbook all the interventions carried out on the machine.

This section describes the ordinary checking and maintenance procedures needed to guarantee the correct functioning of the machine.

Any other intervention that may be necessary to eliminate anomalies or faults must be expressly authorized by the manufacturer.

For major repairs it is recommended to turn to the manufacturer whose specialized personnel, possessing the technical expertise acquired from the original manufacturing in the factory, are always reachable and able to intervene quickly.

For maintenance or replacement of commercial components installed on the machine keep to the instructions provided directly by the manufacturers.

Such instructions are normally attached to the components or obtainable via catalogues or manuals provided by the manufacturers.

Environment

The components replaced during maintenance operations must be disposed of according to the laws in force concerning waste materials. If necessary, they can be sent to the manufacturer, who will dispose of them in the most appropriate manner.

6.2. General safety practice

Attention

Before starting a maintenance procedure disconnect the machine from the mains and put in place all the necessary safety measures.

Attention

During maintenance procedures place on the machine, preferably on the control panel but in any case in a clearly visible location, a sign with the text: "MACHINE UNDER MAINTENANCE, DO NOT SWITCH ON".

Maintenance work must be carried out by specialised technicians who are trained in specific sectors, which for this machine are:

- mechanical maintenance technicians;
- electrical maintenance technicians.

It is the duty of the Safety Officer to ascertain the professionalism and competence of the maintenance technicians.

Before starting a maintenance procedure the safety officer must:

- 1) Clear the working area of extraneous materials and people.
- 2) Make sure that the necessary tools are conveniently available to the maintenance technician and that they are in good condition.
- 3) Make sure that the lighting is sufficient and provide, if necessary, portable low voltage lights.
- 4) Make sure that the maintenance technician is equipped with the necessary approved personal protection equipment for the specific operation (gloves, safety glasses, shoes, etc.).
- 5) Make sure that the maintenance technician has carefully read the instructions contained in this manual and has excellent knowledge of how the machine works.

At the end of every maintenance intervention the following procedures need to be carried out before restarting the machine:

- 1) Carefully clean the floor in the work area, removing any residues that may cause slippage
- 2) Lock the protective panels back into place, check the functionality of the interlocking parts and of the safety devices. Make sure to re-activate them if they were previously deactivated
- 3) Make sure that no extraneous components have been left in the machine, especially mechanical parts, utensils or components used for maintenance that could cause damage to the machine or put personnel at risk.
- 4) Before switching the machine back on make sure that all personnel are at a safety distance.
- 5) Before restarting the processing, the maintenance technician must check the entire working cycle, the functionality of the safety mechanisms and the integrity of the fixed protective panels.
- 6) before restarting the working cycle the machine must be cleaned.

Attention

Following every maintenance intervention it is the Safety Officer duty to ascertain that the machine is working properly and that all the safety devices are present and functional.

Unless expressly required for the solution of a breakdown, never interfere with the adjustments and positioning of the limit microswitches; their tempering can cause serious damage to the machine and pose risks to the operator.

Before assembling a block always cover with a thin layer of alimentary grade oil the internal parts and coupled surfaces. replace all the seals and gaskets with original parts before reassembling the components.

Note

Before reinstalling the machine components that have been washed with water or other liquids, check that they are completely dry.

Work on electrical components must only be carried out by the electrical maintenance technician specially trained and authorized by the Safety Officer.

MAIN OPERATION OF CLEANING AND MAINTENANCE


EVERT WORKING DAY:

Empty the tray of the skin collector

ATTENTION: DO THIS OPERATION ONLY WHEN THE MACHINE IS SWITCHED OFF



pull up and release the
two side fastening
elements




- Extract the tray
- Empty the tray
- Replace the tray
- Close the fastenings


EVERY WEEK

Clean the glass window of the roasting chamber

ATTENTION: BEFORE TO MAKE THE OPERATION: BE SURE THE MACHINE IS SWITCHED OFF AND UNPLUGGED FROM THE ELECTRICAL CONNECTION



Unscrew the two knobs and extract the glass





- Clean the glass
- Replace it
- Screw the two knobs

EVERY WEEK

Cleaning the air distribution cone

ATTENTION: BEFORE TO MAKE THE OPERATION: BE SURE THE MACHINE IS SWITCHED OFF AND UNPLUGGED FROM THE ELECTRICAL CONNECTION



4



5



6



7



- With a wire:
- Insert the wire in each hole
- Verify that all the holes are free from dirt

- Replace the cone with the three screws
- Replace the left panel with the 4 screws

EVERY WEEK

Clean the roasting chamber from the skin rest that are stuck inside

ATTENTION: BEFORE TO MAKE THE OPERATION: BE SURE THE MACHINE IS SWITCHED OFF AND UNPLUGGED FROM THE ELECTRICAL CONNECTION



1

pull up and release the three side fastening elements



Leave the cover beside the machine

Uncrew the level sensor connection

3



4



Unscrew the level sensor

5



6




Unscrew the three nuts of the roasting chamber cover:
in this order, first the two in the sides, then the front one

7



8



Pull up the cover and place
block to hold it up

9



Remove the central tube/air
distribution element

10



With air compressed, brush and a cloth
clean the roasting chamber in every
point.

10




Clean in the same way also the upper
part / cover of the roasting chamber

11



Clean carefully the points where the roasting air is flowing:


- The grill ring
- The lateral slots



EVERY WEEK


Clean the cooling chamber

ATTENTION: BEFORE TO MAKE THE OPERATION: BE SURE THE MACHINE IS SWITCHED OFF AND UNPLUGGED FROM THE ELECTRICAL CONNECTION



- Remove the right panel:
- Unscrew the 4 screws
- Remove the panel

With air compressed blow inside the cooling chamber and remove all the particles that are inside.




EVERY 15 DAYS

Cleaning the filter

ATTENTION: BEFORE TO MAKE THE OPERATION: BE SURE THE MACHINE IS SWITCHED OFF AND UNPLUGGED FROM THE ELECTRICAL CONNECTION

On the backside of the machine, unscrew the four nuts (G) that are fastening the back panel.


Blow with air compressed on the filters and free them from the dirt.




EVERY 6 MONTHS


(depends on how much the machine worked and in which conditions are the filters)


Change the filters with new ones.







REV.	MODIFICA	DATA	FIRMA	APPR.	SOST. IL :	SOST. DA :	FILE :	Alimentazione Circuiti Ausiliari	ROASTER 120	2017_07_002_R120	FG. 11
											F.S. 12















REV.	MODIFICA	DATA	FIRMA	APPR.	SOST. IL :	SOST. DA :	FILE :	2017_07_002_R120	FG. 13	F.S. 14










8. Section spare parts

	RST120 001 Emergency button
	RST120 002 START/RESET button
	RST120 003 Power board
	RST120 004 Display Touch screen
	RST120 011 Connecting cable between microcircuit board and power board
	RST120 014 General contactor
	RST120 007 Transformer 220 V - 24 V
	RST120 008 Security protection
	RST120 009 Inverter

	RST120 011 220V Fuse protection
	RST120 012 Electrical panel Cooling fan
	RST120 013 Security relay
	RST120 014 Electrical panel door microswitch
	RST120 015 Roasting chamber Led light
	RST120 016 Roasting chamber Glass
	RST120 017 Sensor level
	RST120 018 Blower for product loading aspiration

	RST120 019 Roasting chamber bottom blower		RST120 028 Manometer
	RST120 020 Roasting chamber side blower		RST120 029 Electrovalves
	RST120 021 Cooling fan		RST120 030 Filters
	RST120 022 Piston between roasting and cooling chamber		RST120 031 Mechanical pivot wheel
	RST120 023 Piston to unload the product		RST120 032 Fuse kit
	RST120 024 Cooling mixer motor		RST120 033 Temperature probe/sensor 6x100 wire length 2m
	RST120 025 Cooling mixer reducer		RST120 034 Loading flexible pipe
	RST120 026 Electrical resistance for the bottom blower		RST120 035 Aspiration exhaust flexible pipe
	RST120 027 Electrical resistance for the side blower		RST120 036 Exhaust flexible pipe

	<p>RST120 037 blower flexible pipe</p>
	<p>RST120 038 Air compressed connection plug</p>
	<p>RST120 039 Air compressed pipe connections</p>
